

INSTALL INSTRUCTIONS

Linux*

1. Install Intel® Firmware Engine Release 4.0 ([Intel® Firmware Engine_R4.0\(Linux\).zip](#)) if it is not currently installed. Follow the getting started steps in the Intel® Firmware Engine quick start guide ([Quick start guide_eng.pdf](#))
2. Open a command Terminal in the directory where downloaded program file (.bin) is located.
3. Change the .bin file properties to include 'execute' and grant required permissions using the following command:

```
'sudo chmod 777 ./ IntelFirmwareEngineATOME3900Setup_1_0.bin'
```
4. To install, type `'sudo ./ IntelFirmwareEngineATOME3900Setup_1_0.bin'`
5. Follow the installer click-through menus to complete installation
6. After installation, open Intel® Firmware Engine 4.0 and select 'New Project ...' from the File dialogue. Under 'Source project', verify 'Intel Atom(R) processor E3900 platform' appears as option in the drop-down box

* Other names and brands may be claimed as the property of others.