

INSTALLATION INSTRUCTIONS

Note: Previous versions of the Intel® Firmware Engine must be uninstalled prior to installing this release. If the previous version of the application is 5.0 or greater, then previously installed platforms must also be uninstalled. Please backup any prior work before performing the uninstall operations.

Windows*

1. Under 'Control Panel', use the 'Uninstall a program' menu to uninstall any previous versions of Intel® Firmware Engine. Please backup any prior work prior to performing the uninstall operation. Check the Quick Start Guide for system requirements prior to installing the latest version.
2. Execute the "IntelFirmwareEngineApplicationSetup_5_0.exe" file and follow the click through menus.
3. If the previous version of Intel® Firmware Engine is 5.0 or greater, the previously installed platforms must also be uninstalled.
4. Install the desired Intel® Firmware Engine Platform package compatible with this release. For release 5.0 the MinnowBoardTubotB21Setup_1_0.exe is compatible.
 - a. Execute the 'MinnowBoardTubotB21Setup_1_0.exe' file and follow the click through menus.