

INSTALLATION INSTRUCTIONS

Note: Previous versions of this Platform installed for Intel® Firmware Engine must be uninstalled prior to installing this release.

Linux*

To uninstall:

1. Open a command Terminal in the directory to the directory where the MinnowBoard TurbotB21 Reference Platform was installed (typically /opt/Intel/MinnowBoard TurbotB21 Reference Platform 1.0.0)
2. Execute the command "Change Intel(R) Firmware Engine platform project Installation" from a command Terminal, type:
`'sudo ./Change\ Intel\ (R)\ \ Firmware\ Engine\ Platform\ Project\ Installation'`
3. Follow the uninstall instructions and keep any prior work desired.

To install:

1. Install Intel® Firmware Engine Release Application 5.0 (Intel® Firmware Engine_R5.0 (Linux) .zip) if it is not already installed. Follow the getting started steps in the Intel® Firmware Engine quick start guide (Quick start guide_eng.pdf)
2. Open a command Terminal in the directory where the downloaded program file (.bin) is located.
3. Change the .bin file properties to include 'execute' using the 'chmod +x' command.
4. Type '`sudo ./ MinnowBoardTurbotB21Setup_1_0.bin`' on the command line.
5. Follow the installer click-through menus to complete installation.